

0800 607 028 sales@windsorhardware.co.nz windsorhardware.co.nz


BRASS CABINET KNOBS


Product codes:

6520 6521 6522 6523 6524 6525









Includes:

- 1x Brass Cabinet Knob
- 1x M5 Screw*
- 1x Washer
- 1x Mounting Disc (optional)
- Mark the fixing position for the cabinet knob on the door/drawer. Ensure adequate space is provided for clearance of knuckles when opening cabinetry.
- 2. Drill one 5.5mm diameter hole at the marked fixing position for the leg centre.
- **3.** Hold the cabinet knob up so the leg aligns with the pre-drilled 5.5mm diameter hole.

Thread the screw through the washer, then the cabinet front, into mounting discs (if including) finishing with the leg of the cabinet knob.

Tighten the screw by using a screwdriver to fix them in position.

4. Ensure that you do not over tighten the screw. The washer should not bite in.