


ARCHITECTURAL LEVER SET


Product codes:

8091 | 8100 | 8110 | 8129 | 8133 | 8143


Architectural Lever Sets are typically used on double doors without a latch. If used with a mortice lock refer to mortice lock instructions.



1. Establish the height and position for the handles on the door.
2. Mark the face of the door each side for drilling a 25mm diameter spindle hole. Match the backset measurement of the passage doors throughout your home. For clean cut-outs, drill from both sides, meeting in the middle of the door. Mark and drill two 6mm screw holes at 19mm to the left and to the right of the centre of the spindle hole. Enlarge the first 5mm of these holes to 7.5mm to fit the lugs on the plates.



3. Loosen the grubscrew on the side of the rose of the lever with the mounting plate (handle 'B') and remove the mounting plate.
4. Fit the mounting plate onto the face of the door by inserting the long through fixing bolts into the face of the mounting plate at two horizontal positions. Pass the bolts through the screw holes and fix into the lever of handle 'A' on the opposite side of the door. Trim the bolts to the correct length if necessary.



5. Insert the spindle into the spindle hole and into handle 'A'. Ensure the grooved side of the spindle will align with the grubscrews on the handles. Slide handle 'B' over the spindle onto the mounting plate, press against the door and tighten the grubscrew on the side of the rose to the mounting plate. Tighten the grubscrews on the side of the levers onto the spindle for each side of the door.

Note: The grubscrews may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used, Windsor code:1276