



NIDO PRIVACY SET

Product codes: 8400 | 8410


To view an easy to follow how-to video for installing this product visit windsorhardware.co.nz/installation.





1. Measure the door thickness and mark the centre of the door edge at the desired height for the bolt.
2. Drill a 25mm (1") diameter hole through the door edge to a depth of at least 90mm. Ensure this hole is square to the door.
3. Mark the face of the door each side for drilling a 25mm diameter spindle hole. The centre of the spindle hole will need to be 57mm from the door edge (backset). Mark two screw holes at 21mm above and below the centre of the spindle hole. Drill the screw holes to 6mm to accept the threaded sleeves. For clean cut-outs, drill from both sides, meeting in the middle of the door.





4. Insert the bolt and faceplate, scribe around the faceplate, remove, then chisel out recess to enable the bolt faceplate to sit flush with the door edge.
5. Remove any loose saw dust and insert the bolt, attach the faceplate and secure it with the wood screws provided.



6. Insert the spindle into the bolt so an even amount protrudes on each side of the door. Ensure the grooved side of the spindle is aligned with the grubscrews on the turn.




7. Insert the short through fixing bolts into the threaded sleeves (1). Then insert those sleeves through the face of the rose of the turn side. Slide the turn over the spindle and press against the door.



8. Slide the release on the opposite side of the door over the spindle and press against the door. Insert the long bolts through the face of the rose of the release side and tighten them into the threaded sleeves.
9. Screw the rose covers onto the roses and tighten the grubscrew on the side of the turn onto the spindle.

Note: The grubscrews may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used, Windsor code:1276



10. Close the door against the frame and mark the latch position for fitting of the striker.
11. Router or chisel so the striker fits flush, allowing for the plastic dustbox behind the striker.
12. Secure the striker with the wood screws provided.